



## **MAGNETIC TOUCH LATCH**

**16-7-4331**

Lightly push to open the door.

When closing, magnet will catch the door by lightly pushing.

For overlay doors, make a 3.5mm gap between door and cabinet frame.

Body: ABS

Counter plate and yoke: steel zinc chromate

Included:

- Counter plate
- 4 round head wood screws 3.1 x 13 mm
- 1 countersunk head screw 2.7 x 13 mm.

<b>A</b>	43.5 mm
<b>Material</b>	ABS
<b>Weight (g)</b>	22 g
<b>B</b>	36 mm
<b>C</b>	15 mm
<b>Finish</b>	white
<b>Nouvelle référence</b>	NEW

